

AEG Air Conditioner User Guide

For your comfort during your stay



Welcome to your accommodation. This guide will help you use the air conditioner for a pleasant stay.

Your AEG Comfort 6000 Air Conditioner

- **3 main functions:** Ventilation, Cooling, and Dehumidification
- **Power:** 12,000 BTU Ideal for rooms up to 35m²
- Quiet: Only 64 dB when operating

ĥ

- Control panel: Touch panel with LED display for easy control
 - **Eco-friendly:** R290 refrigerant gas that respects the environment
- **Ventilation Mode:** Ideal for cooling without chilling the air



The Control Panel

- **Power Button:** Turn the device on/off
- Mode: Choose between Ventilation, Cooling, and Dehumidification
- **+ Temperature +:** Increase desired temperature
- **Temperature -:** Decrease desired temperature
- **Speed:** Adjust ventilation speed (Low, Medium, High)
- **5 Timer:** Program automatic shutdown of the device



The touch panel lights up when you touch any button and automatically turns off after 60 seconds of inactivity.

Ventilation Mode - Ideal for Hot Weather

The ventilation mode is particularly useful during hot days to create a pleasant air circulation without cooling the room.

How to use ventilation mode:

- Turn on the device by pressing the **Power** button
- Press the Mode button until the fan icon lights up
- 3 Adjust the ventilation speed with the **Speed** button (Low, Medium, High)
- Direct the air vents to blow air in your desired direction



Other Available Modes

Cooling Mode

Cools the air to the desired temperature. Ideal for very hot days. Set the temperature between 16°C and 30°C according to your comfort.

Dehumidification Mode

Reduces air humidity without cooling the room too much. Perfect for humid days or after a shower to prevent condensation.

Night Mode

Gradually reduces power and noise during the night for peaceful sleep while maintaining a comfortable temperature.



Recommended Mode

Close doors and windows for optimal efficiency, especially in cooling mode.

- Prefer Ventilation mode in hot but not scorching weather economical and effective for creating a cooling sensation.
- Close blinds/curtains during the hottest hours to limit heat entry and reduce the air conditioner's workload.
- **Empty the water tank regularly** if you use the dehumidification function for an extended period.
- Ideal temperature: 24-26°C. Each degree lower increases energy consumption by 7%.



For your comfort and to save energy, use Ventilation mode when the temperature is bearable.

Usage Tips